

EUCO TAMMS THIN PATCH 514

POLYMER-MODIFIED, MULTI-USE REPAIR MORTAR

DESCRIPTION:

Tamms Thin Patch is a polymer-modified, cement-based mortar formulated for repairing non-structural defects in concrete and masonry surfaces.

PRIMARY APPLICATIONS:

- Horizontal, vertical or overhead repairs
- Interior and exterior use
- Fill small holes, honeycomb and spalled areas
- Repoint mortar joints

FEATURES / BENEFITS

- Single-component
- Trowelable repair mortar
- Long-term durability
- Outstanding bond strength
- High strength
- User friendly

TECHNICAL INFORMATION – MATERIAL PROPERTIES AT 24°C

Set Times (ASTM C 266)

Initial Set	± 30 to 50 min
Final Set	± 1 to 2 hours

Compressive Strength MPa (ASTM C 109)

7 Days	> 15
28 Days	> 25

Flexural Strength MPa (ASTM C 348)

7 Days	4.3
28 Days	5.0

Shelf Life 1 Year in original, unopened package

Packaging Tamms Thin Patch is packaged in 25kg bags

Coverage / Yield

A 25kg bag of Tamms Thin Patch will yield ± 14.5lt of material
Applied at the following thickness, one 25kg bag of Tamms Thin Patch will cover:

3mm	4.8m ²
5mm	2.9m ²

Note: Coverage rates are approximate and are for estimating purposes only

DIRECTIONS FOR USE:

Surface Preparation: Concrete surfaces must be structurally sound, free of loose or deteriorated concrete and free of dust, dirt, paint, efflorescence, oil and all other contaminants. Mechanically abrade the surface to achieve a surface profile of light to medium scarifying / shotblasting. Properly clean profiled area. Apply Tamms Thin Patch to pre-saturated surface removing pooled water prior to application.

January 2014 SA



The Euclid Chemical Company

19218 Redwood Rd. • Cleveland, OH 44110

Phone: [216] 531-9222 • Toll-free: [800] 321-7628 • Fax: [216] 531-9596

www.euclidchemical.com

Mixing: One 25kg bag of Tamms Thin Patch will require 4 to 5 litres of potable water. Mix Tamms Thin Patch in a clean container using a slow speed drill and mixing blade. Pour clean water into the clean container and gradually add the Tamms Thin Patch. Mix thoroughly to disperse all ingredients and to achieve a trowelable consistency. Do not use excess water, and do not retemper Tamms Thin Patch.

Application: Apply sufficient pressure to fill all holes and voids, then trowel to a smooth finish. On large areas, use a screed to obtain a uniform level before trowelling. Do not over-trowel. Tamms Thin Patch will achieve initial set in approximately 40 minutes; final set in approximately 1 hour, and cures within 24 hours under normal drying conditions. Maximum thickness of application is 5mm per lift. When applying multiple lifts, allow prior lift to reach final set, score the surface then place the subsequent lift.

Clean-up: Clean all mixing and application equipment with water immediately following use. If material is allowed to dry on a surface, removal becomes extremely difficult.

Precautions / Limitations:

- Do not use for structural repair work where high compressive strengths are required. Use Pro-Struct 528 VO-MCI for vertical or Pro-Struct 529 for horizontal applications.
- Do not apply to frozen or frost-filled surfaces, at temperatures below 4°C or if temperature is expected to fall below 4°C within 24 hours.
- Application temperatures below 16°C will extend set time.
- On windy or hot days or for application in direct sunlight, use wet burlap or plastic sheet for curing.
- Do not use Tamms Thin Patch in joints or cracks that are subject to movement.
- Do not apply Tamms Thin Patch in more than 5mm deep lifts.
- Do not over-work or over-trowel the repair.
- Do not add more water than recommended.
- Protect from rain for 24 hours after placement.
- In all cases, consult the Material Safety Data Sheet before use.



The Euclid Chemical Company

19218 Redwood Rd. • Cleveland, OH 44110

Phone: [216] 531-9222 • Toll-free: [800] 321-7628 • Fax: [216] 531-9596

www.euclidchemical.com